

HP e3000 Right to Use license levels for AD377A



Level 1	Level 2	Level 3	Level 4	Level 5	Level 6	Level 7
918LX	995/200	N4000 1-way, 380-MHz	N4000 2-way, 380-MHz	N4000 2 way, 500-MHz	N4000 3-way, 500-MHz	N4000 3-way, 750-MHz
918RX	997/100	996/500	997/500	997/800	N4000 4-way, 440MHz	N4000 4-way, 750-MHz
928LX	979KS/100	995/600	989KS/400	989KS/550	N4000 3-way, 550-MHz	
928RX	996/200	969KS/400	989KS/350	989KS/650	N4000 4-way, 500-MHz	
A400 1-way 110MHz	959KS/200	989KS/200	989KS/500	N4000 3-way, 440-MHz	N4000 4-way 550-MHz	
968LX	992/300	996/600	997/600	997/1000		
968RX	995/300	969KS/320	N4000 2-way, 440-MHz	997/1200		
990	N4000 1-way, 220-MHz	995/700	989KS/600			
A500 1-way, 140MHz	989KS/100	N4000 1-way, 440-MHz	989KS/450			
929KS/020	969KS/200	997/300				
991	995/400	996/700				
978LX	992/400	979KS/300				
978RX	996/300	995/800				
992/100	A500 2-way, 200-MHz	N4000 1-way, 500-MHz				
939KS	989KS/150	996/800				
929KS/030	959KS/300	989KS/250				
996/80	995/500	969KS/420				
995/100	969KS/220	997/400				
939KS/020	969KS/300	979KS/400				
959KS/100	996/400	989KS/300				
996/100	N4000 1-way, 330-MHz					
A400 1 way, 150-MHz	997/200					
988LX	959KS/400					
988RX	979KS/200					
969KS/100						
939KS/030						
A500 2-way, 140-MHz						
992/200						
A500 1 way, 200-MHz						
969KS/120						